

How to use our printer, Aurora

This guide is to help you print & scan using our Toshiba eStudio 2040CSE named Aurora.

Getting started


If you never used it before, you need to register for printing by following these steps:

1. Visit <http://aurora.nateko.lu.se>
2. Log on using your computer account
3. Click Logout

Once done, you have enabled your account.

Printing

By default, Aurora is set up to print in black & white. If you need color printing, select the Windows printer named *Aurora_Color*, and printouts will be in color.



Note: a color page consumes 10 printing credits, whereas a black & white page consumes only one.


Scanning

Easiest way is to scan directly to a USB stick.



Make sure the USB stick is not using NTFS compression, or the printer won't read it.

Otherwise, save your scans to the network folders, either \\Aurora\file_share or <\\fileserv\aurora>.



Note: scanning to e-mail has not been configured.

Copying

The native copying function is disabled due to accounting reasons. To copy, please scan + print.

